


## Quick Guide

---

### Steps to Update Virtual COM Driver for 1D Scanners

1. Connect the handheld scanner and the host (e.g. a PC) with a USB interface cable.
2. Enable USB virtual COM port with programming barcodes.



Start of Configuration



Enable USB virtual COM



End of Configuration

3. After the programming, the host would request driver installation. Browse your files to locate the driver and start installation. For Windows based systems:
  - Open Device Manager and select the barcode scanner you want to update
  - Select install driver from a specific location.
  - Direct the folder for .inf file.
  - Ignore the warning and continue with installation
  - A COM port is assigned to the scanner when installation is complete.
4. The USB virtual COM port is ready for use after driver installation

**For Z-8082, Z-8072, Z-8072 Plus, Z-3272, Z-3272 Plus, Z-5652, Z-5652 Plus**

1. Install the attached driver for Windows 7/8

2. Scan



3. Scan



4. Scan



**For Z-3392, Z-3392 Plus**

1. Install the attached driver for Windows 7/8

2. Scan



Return as USB-virtual COM


3. Install the attached driver for Windows 7/8

PS. Windows 10 has included virtual COM driver.

**For Z-3392BT, Z-3392BT Plus**

1. Install the attached driver for Windows 7/8

2. Scan




PS. Windows 10 has included virtual COM driver.

: cf`Ca b]X]fYW]cbU`GWUbbYfg

### Steps to Update Virtual COM Driver

1. Connect the handheld scanner and the host (e.g. a PC) with a USB interface cable.
2. Enable USB virtual COM port with programming barcodes.


Enter/Exit Programming Mode



Enable USB virtual COM



Enter/Exit Programming Mode



3. After the programming, the host would request driver installation. Browse your files to locate the driver and start installation. For Windows based systems:

- Open Device Manager and select the barcode scanner you want to update
- Select install driver from a specific location.
- Direct the folder for .inf file.
- Ignore the warning and continue with installation
- A COM port is assigned to the scanner when installation is complete